

NVIS Display Quick Reference Guide

15" NVIS Display

The front mounted buttons and switches control your NVIS display. Some buttons serve more than one function. Each button is labeled with all of its functions in the images below.

Button Layout



1)



Button – Primary Control Function (non Menu Mode)

Button LED Brightness up

2)



Button LED Brightness down

3)



Press to access the menu (OSD - On Screen Display)

4)



Dim to Red: Momentarily press to toggle between standard colors and Red for day time and night time viewing at any brightness level.

5)





ON/OFF: Momentarily press to turn display on or off.

6)



Push and Turn the Potentiometer (dial), clockwise to increase backlight brightness level and counter- clockwise to decrease backlight brightness level.

Switch Layout	Switch – Primary Control Function
	Turns the NVIS feature ON and OFF. Up position is ON down position is OFF.
	Turns the Touch feature ON and OFF. Up position is ON down position is OFF.

See reverse for Installation Guide